# User Manual



Mobile phone

### **Compatibility Note**

- Please ensure that your car is compatible with wired CarPlay or Android Auto.
- The wireless CarPlay feature requires an iPhone 6 or a newer model with iOS 10 or higher.
- The wireless Android Auto feature requires an Android phone with version 11 or higher that supports the latest Android Auto features.

#### To verify if your vehicle supports wired CarPlay or wired Android Auto:

- Connect your iPhone or Android smartphone to the vehicle using a USB data cable. The connection interface logo will then appear on the car's display screen.
- Refer to the compatibility list or contact your car manufacturer directly for confirmation.







carplay/available-models/

https://www.android.com/auto/

# **Apple CarPlay**





- 1.Turn on the vehicle and wait for the system to fully load.
- 2.Insert the adapter into the vehicle's USB-A or USB-C port.
- 3.Once the adapter is successfully connected to the vehicle, the screen will display the adapter's Bluetooth name as "Aziot CarPlay-XXXX".
- 4. Open the Settings on your iPhone and
- enable "Bluetooth" and "Wi-Fi". 5.Go to the "Bluetooth" settings and select the adapter with the prefix "Aziot Carplay -xxxx" from the "OTHER DEVICES" list.

- 6.Wait for about 20-30 seconds, and a "Bluetooth Pairing Request" notification will appear on your phone screen. Click "Pair" to proceed.
- 7.A dialog box will appear on the phone screen asking "Use CarPlay with "Aziot CarPlay-XXXX" Click "Use CarPlay" to establish a connection between your phone and the adapter.
- 8.After Bluetooth pairing is complete and the CarPlay connection is established, the car screen will automatically switch to CarPlay mode.


#### **Switching Different Phones**

- 1.Simultaneously turn off the Bluetooth and Wi-Fi on the currently connected phone.
- 2.Unplug and reinsert the adapter. (Important)
- 3.Turn on the Bluetooth on the other phone, search for and pair with the adapter's Bluetooth named

# "Aziot CarPlay-XXXX".

4.If the system prompts that the Bluetooth is in use, try pairing multiple times to complete the switch.

#### **Android Auto**






- 1.Turn on the vehicle and wait for the system to fully load.
- 2.Insert the adapter into the vehicle's USB-A or USB-C port.
- 3.Once the adapter is successfully connected to the vehicle, the screen will display the adapter's Bluetooth name as "Aziot CarPlay-XXXX".
- 4. Open the Settings on your phone and
- enable "Bluetooth" and " Wi-Fi ". 5.Go to the "Bluetooth" settings, Click "Pair New Device", and select the adapter with

"Available devices" list.

the prefix "Aziot CarPlay-XXXX" from the

- 6.Wait for about 20-30 seconds, and a dialog box will appear on your phone screen asking "Pair with" Aziot CarPlay-XXXX"? Click "Pair" to establish a connection between your phone and the adapter.
- 7.After Bluetooth pairing is complete and the Android Auto connection is established, the car screen will automatically switch to Android Auto mode.

### OTA Online Update



- 1.Power the adapter.
- 2. Open the Settings on your iPhone and enable " Wi-Fi "
- 3.Go to the "Wi-Fi" settings and select the adapter with the prefix "Aziot Carplay -XXXX" from the "NETWORKS" list. default password is "8888888".
- 4.Enter the IP address "192.168.1.101" in your phone's web browser.
- 5.Click "Update" on the OTA page. (Do not exit the page during the upgrade process to avoid interrupting it.)

- 6.Once the upgrade is complete, the page will display "Update Completed."
- 7.Unplug and replug the adapter.
- 8.Delete the old Bluetooth connection on your phone and establish a new Bluetooth connection to start using the upgraded product.

## **LED Light Status**

Red Green light or Red Blue light flashing alternately:

Adapter is powered on

Green light flashing:

Carplay is connecting

Blue light flashing:

Android Auto is connecting

Rainbow light flashing:

Carplay/Android Auto has been connected