

# IR Blaster User Manual



## 1 SETTING UP IR Blaster


1. Download the SmartLife app onto your smartphone. This app available for both iOS and Android devices.



2. Connect your mobile to 2.4 GHz Wi-Fi network.
3. Enable the Location & Bluetooth in your mobile.


## 2 SETTING UP IR BLASTER

4. Install the IR Blaster with the cable into a USB adapter.
5. Check if indicator light is rapidly blinking.
6. If indicator light is not blinking then press and hold the reset button for at least seconds until the network configuration indicator start Blinking.
7. Press on “Confirm indicator rapidly blink” if the indicator light is blinking rapidly.



## 3 SETTING UP IR BLASTER

8. Tap the icon "+" on the top right corner of the 'Smart Life' App, then select Auto Scan, and the device will be automatically discovered and click 'Go to add' on the prompt.
9. Follow the app instructions to connect the IR Blaster to your Wi-Fi network.
10. You can change name if required and press completed



## 4 SETTING UP REMOTES ON IR BLASTER

1. Open IR blaster from SmartLife app
2. Click on add remote control
3. Select device-example TV
4. Search TV brand and click
5. Check IR blaster remote compatibility with any 3 buttons, if the device is getting controlled then Press Select the One at bottom left.
6. If not then change remote by clicking “Next one” at bottom right corner
7. Repeat the process till you find the compatible remote.

## 5 CONNECTING TO VOICE ASSISTANT

Search and enable “Smart Life” Skill in Alexa and Google Home. Follow the on-screen instructions to complete the Voice Assistants Setup.

