

Smart Handle Lock

User Manual

Dear user; Thank you for purchasing the smart door lock

To improve the quality survival with innovative technology, to create the world's most outstanding, most innovative products so that enterprises become the industry benchmark .We always adhere to the " quality survival, service and development" business philosophy. In the intelligent lock industry, all constantly improve the product quality system, our company keep up with the pace of the times . We always walk in the forefront of the industry, and always steadfastly protects the people's

property safety! From products to service ,we always pursue to provide you with a full range of intimate and comfortable service!Thank you for your support for smart door lock!!

Installation Steps

STEP 1:



Pass the square along the wire



the corresponding length according to the and tighten the screws





2 The hole position can be adjusted according to the door lock position

Install and fix the door

STEP 3:

STEP 4:









Install the deadbolt



STEP 6:







1.Pay attention to the direction of the lock tongue when you installing



After completing the above steps,the door lock installation is complete (2)

FINGERPRINT LOCK INSTALLATION INSTRUCTIONS

















Device Configuration:

The smart handle door lock is equipped with two buttons:

- S1 Button: Located visibly on the door handle, this button allows you to unlock the door from inside the home
- S2 Button: This button is concealed inside a small hole on the door handle.

Entering Configuration Mode:

To put the device into configuration mode, press and hold the S2 button for 5 seconds. You will hear five short beeps, and the handle will display a red light indicator, confirming that the lock is now in configuration mode.


Once in configuration mode, you can proceed with the setup using the Smart Life App

Download SmartLife App from Android Playstore or App Store



Packing List

Open the product package. Check that the following accessories are included.






Diagram of Door Lock Installation

.APP registration,login



APP registration choose to register if without an APP account or log in through SMS verication code.

page Get SMS verification code and set passwore according to the prompt.

If you already have an existing account, you can click "Log In" to login in to the app. Enable the Location and Bluetooth in your mobile







- 1. Tap the icon "+" on the top right corner of the 'Smart Life' App, then select Auto Scan, and the device will be automatically discovered and click 'Go to add' on the prompt. 2. Tap the icon "+" besides the bluetooth device.
- 3. Follow the app instructions to connect the Smart Handle Lock to your Bluetooth.
- 4. Once connected, the app will prompt the connection, and click 'Done'.

(1)

II. Member management-family member management



1. Validity period once added,the permission ofusing time of family members is permanent until the administrator deletes the member, and the members always have the corresponding permission.

2.Door opening method:The administrator car decide the permission type of the member As shown opening permissions of the member the user can on onger maintain his own door opening mode through APP and can only use the existing door opening

3.Create/delete the door opening mode. By connecting the doorlook with APP Bluetooth the inistrator can create/delete the door opening for other family members

III.Member management-other member managemen



1. Validity period the administrator can decide the length of validity period of other members. It can be set as permanent or set the specified start time-end

2.Door opening mode the administrator can decide the permission type of the door opening mode possessed by the member As shown in the foure if the administrator coses at the door opening permissions of the member, the user can no longer maintain his own door opening mode through APP, and can only use the existing door opening mode. 3.After creating another member,the administru can associate the member with a certain user of APP by "sharing". When the specified end time of the user arrives the user's APP will automatically lose the

IV.Fingerprint manage



1.Select "Member Management" 2 Click on the "User 3.Add the Fingerprint

V .Password management

1. Select "password management" as the entry of the home page.

2.Before adding a password,select the user corresponding to the password to be added.

3.Click "Add Password"to enter the password entry interface which supports random generation and user-defined

passworus 4. Connect the door lock through APP Bluetooth, and the administrator can enter the password for himself or other family members

VI . Door opening record.

The log can be queried in the Door Opining Reconflimity of the homepage, and the records are arranged in revenue order The unlocking ID that has been associated with the user name will directly display the corresponding user name and the unlocking ID that has not been associated with the name from the APP will display the specific unlocking ID: and the directoring to that has not cent associated well as name than the her was appear the special circles of About the record of door apening with the door look is connected with Bulletooth of mobile phone, the record of door apening will be displayed on APP in real time, otherwise, the record will be cached locally in the door look and it will be retransmitted affer the door look is connected with Rivetooth of mobile obone and opened next time

VII .Restore the factory settings

Click the icon in the upper right corner of the main page, enter the interface, find "Remove device" and select "Unbind and

1. When the metilie phone APP is connected to the door lock by Studooth the factory reset operation is used. Allocal 1. When the insiste profile APP is connected to the door look by statebook he restored to its original factory default state. Other users can re-add the door look will be desired and the door look will be restored to its original factory default state. Other users can re-add the door look through APP.

3.Press the setting button in the small hole of the rear handle for 5 seconds and the door lock will make a long "disp" sound, which will force the factory settings to be restored. All the door opening methods on the door tock will be deleted, and the door lock will be restored to its original factory default state. Other users can add the door lock again through APP

4

4.Emergency Unlock

Method 1:

STEP 1:



Plug the USB power cord into the connector

STEP 2:



Press the registered administrator fingerprint

STEP 3:



Unlocking is successful

Useful Tips

1.Keep atlest one key out of the door for emergency.

2. When the battery is low, the indicator will blink red light, the rest power could only be used for about 50 times.

3. When the battery is out of power, you can unlock the door with key, or supply the lock with power through the microUSB and use fingerprint or password to unlock it.

4.Use alkaline betteries to prevent the damage by battery leakage.Batteries must be replaced every 2 years.

Product Parameters

- 1.Number of Fingerprints 50
- 2. Number of Passwords 100
- 3. Power Supply 4 AAA 1.5V Alkaline Batteries.

Useful Tips:

- 1.Keep at least one key out of the door for emergency.
- 2. When the battery is low, the indicator will blink red light. The rest power could only beused for about 50 times.
- 3. When the battery is out of power, you can unlock the door with key, or supply the lockwith power through the micro-USB port and use fingerprint or password
- 4. Use alkaline batteries to prevent the damage by battery leakage. Batteries must be replaced every 2 years.

Q&A:

Q:The button doesn't respond and light doesn't light up?

A:Check the cable is it connect to the right way or it's loose,After this it's still can't work, normally it's the battery dead. It needs to change the batteries (4*1.5V AAA battery), or pull out the inner back cover and insert it again.

Q:Which model of the door can install the fingerprint door lock?

A:There is no limit. If the door thickness more than 3,5cm-6,5cm then it can install.

O:How to restore the factory settings ?

A:Long click the setting button 5s,the blue light will shinning and have the beesound, After 5s will have the red lighshinningandhaveavoiceremainder initial success, This

Q:What is the initial password if the fingerprint lock is restored to the factory setting? A:Initial password is "123456"#

Q:How to do if the lock run out of the battery?

A:Use the power bank to connect the USB port to charge then use of use the key toopen the door.

Q:How to do if you forget the password?

A:Use the fingerprint or key to unlocked the door and then restore the factory settingsto reset the password.

Other Settings

1.Two Ways to Reset and Delete All the Users

Method 1:

STEP 1:





Long press the small hole on the inside handle with a small screwdriver for 9 seconds





When the indicator blinks red light,stop the operation,the reset is successful

Method 2:





Press the registered

adminis-trator fingerprint.

the reset is successful

Enter 888"+"#" and the indicator will blink red light

Method 1:

STEP 1:



2.Two Ways to Turn ON Normally- Open Mode

Long press the button onthe inside handle for 1 second

Method 2:

STEP 1:



Touch to wake up the password area



When the indicator light

turns Blue ,release the

STEP 2:

button

Enter*28"+"#",and theindicatror will blink Blue light

STEP 3



Press the registered adminis trator fingerprint

3.Four Ways to Turn OFF Normally-Open Mode a.Repeat the above 2 methods to turn off the normally open mode b.Press *#"to lock and turn off the normally open mode c.Enter an enrolled fingerprint or password to lockup



Customer Care: +91 88866 35918 / support@aziot.life

Website: www.aziot.life Follow us on: Aziot.life











(5)